


- 1) Open the Trigger Z software by double clicking the icon in the system tray. Downloadable from [www.gaming.coolermaster.com](http://www.gaming.coolermaster.com)



- 2) Choose the profile you wish to set the windows or FN key for



- 3) Click on the FN Key on the software keyboard layout



- 4) Click on the Windows logo to activate or deactivate the key as a windows key. Or set it to Storm to set it to a FN function. Or no function at all.



- 5) Your key assignment will be shown on the right panel under "All Key List".



- 6) Click on the X to close and update the settings



- 7) Hold down the right FN key and press ~,1,2,3,4,5 to select the profile you just adjusted or created.  
~ = default  
1,2,3,4,5 = profile 1-5